

DUSS

Spare part list

Rotary hammer

P16SDS

Description	Part no.	Piece / machine	Description	Part no.	Piece / machine
O-ring seal 9,5x1,6	P16SDS-9	1	Sticker "R-L"	P16SDS-59	1
O-ring seal 24x4	P16SDS-10	1	Carbon brush	P16SDS-61	2
Tool bit driver	P16SDS-11	1	Brush holder	P16SDS-62	2
Circlip	P16SDS-12	1	Hexagon nut M5	P16SDS-63	1
Spring	P16SDS-13	2	Star knob	P16SDS-64	1
Clutch spring	P16SDS-14	1	Clamping collar	P16SDS-65	1
Pin	P16SDS-15	1	Side handle	P16SDS-66	1
Spindle gear	P16SDS-16	1	Clamping collar, assembled	P16SDS-66K	0
Roller 3x9,8	P16SDS-17	4	Nut M10	P16SDS-67	1
O-ring seal 38x5	P16SDS-18	1	Depth stop	P16SDS-68	1
Washer	P16SDS-19	2	Cap	P16SDS-69	1
Needle thrust bearing	P16SDS-20	1	Washer	P16SDS-70	1
Friction sleeve	P16SDS-21	1	Armature, 230 V	P16SDS-71	1
Hexagon socket screw M4x12	P16SDS-22	2	Screw 4x48	P16SDS-72	4
Cylinder	P16SDS-23	1	Ball bearing	P16SDS-73	1
Striker	P16SDS-24	1	Field, 230V	P16SDS-74	1
Striker ring	P16SDS-25	1	RFJ choke, black	P16SDS-75	1
Piston	P16SDS-26	1	RFJ choke, blue	P16SDS-76	1
Piston pin	P16SDS-27	1	Reverser	P16SDS-77	0
Support washer	P16SDS-28	2	Switch	P16SDS-78	1
Washer	P16SDS-29	4	Capacitor	P16SDS-79	1
Needle thrust bearing	P16SDS-30	2	Cord sleeve	P16SDS-80	1
Disk spring	P16SDS-31	1	Cord clamp	P16SDS-81	1
Countershaft	P16SDS-32	1	Cord and plug	P16SDS-82	1
Circlip	P16SDS-33	1	Dust protection cap	P16SDS-201	1
Spring	P16SDS-34	1	Locking bushing	P16SDS-202	1
Clutch dog	P16SDS-35	1	Retaining ring RW 18	P16SDS-203	2
Pivot bearing	P16SDS-36	1	Ring	P16SDS-204	1
Gear wheel	P16SDS-37	1	Steel sleeve	P16SDS-205	1
Screw M4x10	P16SDS-38	1	Retainer	P16SDS-206	1
Pneumatic housing	P16SDS-39	1	Spring	P16SDS-207	1
O-ring seal 5x1,5	P16SDS-40	1	Aluminium sleeve	P16SDS-209	1
Change lever	P16SDS-41	1	Ball 7 mm dia.	P16SDS-210	2
Front cover	P16SDS-42	1	Chuck	P16SDS-211	1
Screw M4x25	P16SDS-43	2	Chuck, assembled	P16SDS-211K	0
Lock washer M4	P16SDS-44	4	Ram	P16SDS-212	1
Screw M4x16	P16SDS-45	2	Nameplate	P16SDS-213	1
Needle bearing	P16SDS-46	2	DUSS sticker	P16SDS-214	2
Dust seal	P16SDS-47	1			0
Needle bearing	P16SDS-48	1			0
Gasket	P16SDS-49	1			0
V-ring seal	P16SDS-50	1			0
Spring	P16SDS-51	1			0
Ball 4mm dia.	P16SDS-52	1			0
Cylinder housing	P16SDS-53	1			0
Screw 4x14	P16SDS-54	8			0
Screw 4x20	P16SDS-54a	2			0
Ball bearing	P16SDS-55	1			0
Baffle plate	P16SDS-56	1			0
Motor housing	P16SDS-57	1			0

DUSS

P 16 SDS

