DUSS

Spare part list

Combi hammer P60A

Description	Part no.	Piece / machine	Description	Part no.	Piece / machine
Tool retainer	P60A-1	1	Clutch spring	P60A-50	1
Tool retainer with shock absorber	P60A-1+3	0	Support washer	P60A-51	1
Bolt	P60A-2	1	Damper	P60A-52	1
Shock absorber	P60A-3	2	Friction sleeve	P60A-53	1
Washer	P60A-4	1	Axial damper	P60A-54	1
Splint	P60A-5	1	Clutch	P60A-55	1
Clamping collar with jaw	P60A-6	1	Needle bush	P60A-56	1
Clamping collar, assembled	P60A-6K	0	Crank shaft	P60A-57	1
Nut M12	P60A-7	1	Ball bearing	P60A-58	1
Front cover	P60A-9	1	Gear wheel	P60A-59	1
Gasket	P60A-11	1	Gasket	P60A-60	1
Dust seal	P60A-12	1	Grooved pin	P60A-63	4
Sleeve bearing	P60A-13	1	Sleeve bearing	P60A-64	2
Clutch dog	P60A-14	1	Ball bearing	P60A-65	1
Damper ring	P60A-15	1	Ball bearing	P60A-67	1
Tool bit driver	P60A-16	1	O-ring seal 26x2	P60A-68	1
Ram	P60A-17	1	Plain washer for V-ring	P60A-69	1
Seal	P60A-18	1	Ball bearing	P60A-70	1
Seal	P60A-19	2	Retaining ring	P60A-71	1
Ram guide	P60A-20	1	Washer	P60A-72	1
Screw M6x90	P60A-21	4	Armature , 230 V	P60A-73	1
Copper washer M6	P60A-22A	4	Ball bearing	P60A-74	1
Shaft	P60A-24	1	V-ring seal	P60A-75	1
Spring	P60A-25	1	Pinion	P60A-76	1
Ball 3,5 mm dia.	P60A-26	1	Layshaft gear	P60A-77	1
O-ring seal 20x1	P60A-27	1	Gear wheel	P60A-78	1
Flange	P60A-28	1	Bevel gear pinion	P60A-79	1
O-ring seal 13x1,5	P60A-29	1	Copper washer M5	P60A-80	6
Change lever	P60A-30	1	Hexagon socket screwh.c.s. M5x20	P60A-81	6
Change lever, assembled	P60A-30K	0	Screw 4x48	P60A-84	2
Lock washer M4	P60A-31	2	Insulating housing	P60A-85	1
Hexagon socket screw M4x12	P60A-32	2	Rubber sleeve	P60A-86	1
Serrated washer	P60A-33	2	Brush holder	P60A-87	2
Screw M4x10	P60A-34	2	Screw 3x10	P60A-89	4
Cylinder housing	P60A-35	1	Motor cover	P60A-91	1
Needle bush	P60A-36	1	Screw M4x20	P60A-92	4
Connecting rod	P60A-38	1	Potentiometer	P60A-100	1
Piston	P60A-39	1	Cord clamp	P60A-101	1
Piston	P60A-39k	0	Screw 4x14	P60A-102	2
Piston pin	P60A-40	1	Cord sleeve	P60A-103	1
Spring lock washer	P60A-41	2	Cord and plug	P60A-104	1
Piston ring	P60A-42	2	Screw 4x20	P60A-105	2
Striker	P60A-43	1	Spring	P60A-107	1
Cylinder	P60A-44	1	Side handle	P60A-200	1
Sleeve bearing	P60A-45	1	O-ring seal 14x4	P60A-201	1
O-ring seal 49x3,5	P60A-45A	1	Switch	P60A-202	1
Damper washer	P60A-46	1	Field, 230V	P60A-203	1
Retaining ring	P60A-47	1	Electronics ass'y	P60A-204	1
Roller 3x11,8	P60A-48	4	Carbon brush	P60A-205	1
Pin	P60A-49	1	Carbon brush with wire strand	P60A-206	1

DUSS

Spare part list

Combi hammer P60A

Description	Part no.	Piece / machine	Description	Part no.	Piece / machine
Nameplate	P60A-207	1	Pressure spring	P60A-225	8
DUSS sticker	P60A-208	2	Antivibration mass	P60A-226	1
Motor housing	P60A-209	1	Space hull	P60A-227	0
Ventilation insert, right	P60A-210	1	Spring plate	P60A-228	1
Ventilation insert, left	P60A-211	1	Disk spring	P60A-229	1
Sticker "RVA"	P60A-212	1	Screw 4x27	P60A-230	1
Fitting for the diodes	P60A-213	1	Washer	P60A-231	2
Washer	P60A-214	4	Vibration absorber housing	P60A-232	1
Screw M5x60	P60A-215	2	Vibration absorber	P60A-233	1
Hexagon socket screw M5x65	P60A-216	2	Vibration absorber housing ass'y	P60A-233k	0
Nut M12	P60A-217	1	Spacer	P60A-234	2
O-ring seal 8x3	P60A-218	1	Pressure spring	P60A-235	2
Side handle	P60A-219	1	Vibration absorber	P60A-236	1
Handle	P60A-220	1	Disk spring	P60A-237	1
Pressure spring	P60A-221	2	Screw 4x12	P60A-238	1
Vibration absorber housing	P60A-222	1	Spacer with guidance	P60A-239	2
Vibration absorber housing, ass'y	P60A-222k	0	Pressure spring	P60A-240	2
Spacer	P60A-223	0			0
Pressure spring	P60A-224	0			0

DUSS

P60A


21
22a
9
11
12
13
14
15
16
17
18
19
20
222k
219
218
217
214
216
107
100
220
214
215
213
101
102
103
104
24
26
25
27
28
29
30
30k
33
34
31
32
222
239
225
226
225
240
228
229
230
231
232
221
105
202
105
212
81
80
39k
41
40
39
41
38
36
35
60
233
234
235
236
237
238
233k
55
52
54
53
51
49
50
47
46
45
45a
48
44
43
42
6k
5
4
6
3
7
139
2
201
200
84
203
85
91
92
75
68
69
70
71
72
73
86
74
79
78
67
64
65
56
77
76
57
58
59
64
209
205
87
89
204
206
80
63
207
81
210
211
208
222k
222
223
224
225
226
227
225
228
224
229
230
231
232
alte Ausführung bis Maschinen Nr.
22805-01/2015
first version assembled up to serial no.
22805-01/2015
première version assemblage jusqu'à no.
22805-01/2015
04/15